

CANON PG5/CLI8



Refill Volume

20 ml Black approx.
10 ml Colour approx.

Re-fill Instructions

1. Locate fill hole on top of cartridge under label - it may not be directly under the 'push' sign but is easily felt. It will be sealed with a nylon ball bearing. Remove the label just above the push sign.

Note: Don't remove the whole label.

2. Seal ink path by placing rubber band around the cartridge covering the ink path.

3. Push the ball bearing into the cartridge. (You will replace it later with a plug).

4. Fill cavity with ink Wait for ink to soak into sponge section

5. Continue filling & waiting until cartridge is full.

6. Push small black plug into the fill hole. The fill hole must be sealed or the cartridge will leak.

7. Remove rubber band from ink path and ensure cartridge is not leaking.

8. Return cartridge to printer and continue printing.



BLOCKED INKJETS appear as small white lines through the printed output - perform a cleaning procedure via the computer or place the printhead in a little warm water for a minute or two or hold the printhead over steam for 30 seconds. The safest method of using steam is to remove the knob from a saucepan lid creating a small hole - place water in the saucepan & boil on a stove. Hold the printhead over the small jet of steam escaping through the small hole in the saucepan lid.

Troubleshooting

This is a relatively problem free cartridge to re-fill.
Please contact PCS should you require further assistance.

Checklist

Black/colour Ink
20ml syringe
Plastic Plug
Re-filling seals

Clean Up

Skin: Scrub with Solvol soap or bleach.

Clothing: Try soaking in Napi-San or similar – however it is best to avoid soiling clothes with this ink!

Bench Top: Methylated spirits will remove ink from laminate or similar surfaces.

